

INSTALLATION INSTRUCTIONS

BOLLARD & PATHWAY

MODEL: LS582 & LS592

INPUT VOLTAGE: 12 V AC 60 Hz



LS582 & LS592: Balitza Mini & Micro

Warranty void if not installed per instructions and local electrical code

WARNING

It is strongly recommended to use a Lumascope transformer

The luminaire should only be used complete with its protective shield (cover)

Luminaire and transformer to be installed by a licensed electrical contractor.

Install in accordance with National Electric Code, ANSI/NFPA 70 or the Canadian Electrical Code, Part I (CEC), CSA C22.1

IMPORTANT

To reduce the risk of FIRE or INJURY

Luminaire to be used for intended purpose only

Do not touch hot lens, guard, or enclosure

Keep lamp away from combustible materials

Do not operate the lighting fixture with missing or damaged components


Use only genuine Lumascope parts to replace damaged or missing components

SAVE THESE INSTRUCTIONS FOR FUTURE MAINTENANCE

1.

Open luminaire


Loosen all three screws at the base of the luminaire and remove the lid.



2.

Mount cover plate on splice box


Feed the cable through the cover and fit the splice box cover with the seal to the splice box using supplied screws.



3.

Fit luminaire base to cover plate


Fasten the fixture base with the seal to the splice box cover with the supplied screws. Connect the cable to the fixture base.



4.

Seal cable entry hole


Seal Cable hole with silicone.



5.

Insert lamp into luminaire


Check the wattage and insert lamp into fixture. Test to ensure lamp and fixture is operational.



6.

Seal luminaire


Put lid over the base plate and tighten screws.



RELAMPING

Lighted lamp is Hot! Allow to cool before replacing. Do not touch the lamp with bare hand at any time as oil from skin may damage lamp.

1. Open fixture as shown in step 2.
2. Remove old lamp from fixture as shown below.



3. Insert lamp into fixture as shown in step 4.
4. Seal fixture as shown in step 5.

Should you experience any difficulty, please contact Lumascope directly: phone (866) 695-5862 or email info@lumascope.com

IF IN DOUBT, PLEASE CALL

www.lumascope.com